

# Reusable Balloon Pole Kit with Steel Ground Spike

# Instructions

## Step 1



Remove reusable balloons from package and inflate until firm.

## Step 2



Slide the adapter clip into the bottom of the reusable balloon. Stretching the folds over the adapter clip and securing on both sides.

## Step 3



Balloon Holder

Take the balloon holder & turn it face down to meet the adapter clip. Align the two open sides of the balloon holder to the adapter clip and click in place.

*(Balloon holder will be secure in place onto the adapter clip after hearing a clicking noise.)*

## Step 4



35" Balloon Pole

Twist and lock balloon holder into the top of the 35" balloon pole.

Please note that while this product can be used anytime of the year it is sensitive to air density.

Here are some suggestions to keep your Reusable Balloons looking their best:

\* Filling the balloon all the way might help it stay inflated. Slight deflation does not mean the Balloon is defective.

\* Do not drag over sharp objects or surfaces. Avoid contact with hot or sharp objects.

\* It is recommended to remove the balloon holder from base when re-inflating the balloon.

## Kit Includes (per 1)

One reusable balloon  
One balloon adapter clip  
One plastic balloon holder  
One 35" aluminum balloon pole  
One ground spike base

## Step 5



Take the ground spike base and place into your desired ground area. (Spike can be hammered or pressed down into ground by hand or foot)

## Step 6



Insert the assembled balloon kit (bottom of 35" balloon pole) into the top opening of the ground spike base.

## Step 7



Balloon kit is assembled!

*Park Place*  
Printing & Promotional Products LLC

Your #1 Source For Auto Dealer Supplies For Over 38 Years!

PO Box 826 • Green Brook, NJ 08812

1-888-602-3123

(732) 529-6900

[www.parkplaceprinting.net](http://www.parkplaceprinting.net)